


PRINCIPLE
REINFORCEMENT DIRECTION


STEP 1 - PLACE REINFORCEMENT SO LITTLE OR NO OVERLAP OCCURS IN THE RADIUS AREA. IF OVERLAP OCCURS, PLACE 2 TO 3 INCHES OF SAND BETWEEN THE REINFORCEMENT LAYERS.

2" TO 3" OF SOIL FILL REQUIRED BETWEEN OVERLAPPED REINFORCEMENT FOR PROPER SOIL AND REINFORCEMENT REACTION




STEP 2 - LAY THE NEXT COURSE OF BLOCK. MAKE A MARK ON THE BACK OF THE BLOCKS IN THE AREAS THAT ARE NOT REINFORCED. BACKFILL AND COMPACT THAT COURSE.

CORES NOT SHOWN FOR CLARITY




STEP 3 - PLACE REINFORCEMENT IN THE AREAS WHERE THE MARKS SHOW GAPS IN THE LOWER REINFORCEMENT PATTERN. CONTINUE NORMAL WALL CONSTRUCTION, REPEATING THESE STEPS AS NEEDED.




CORES NOT SHOWN FOR CLARITY

BEVELED UNITS
MINIMUM RADIUS
2 FEET TO INSIDE



STRAIGHT UNITS
MINIMUM RADIUS
4 FEET TO FACE



**ANCHOR DIAMOND®
OUTSIDE CURVE W/ GRID**
(NOT TO SCALE)

**ANCHOR DIAMOND®
OUTSIDE CURVE**
(SCALE: 3/8" = 1'-0")



These graphical representations are intended for preliminary design purposes only, and are not to be used for construction without the signature of a registered professional engineer.

All information herein © 2005 Anchor Wall Systems

Drawn By: AWS
Date: 4/26/2005
Scale: AS SHOWN

Drawing Title: ANCHOR DIAMOND OUTSIDE CURVE DETAILS
Project Information: ANCHOR RETAINING WALL SYSTEMS TYPICAL WALL DETAILS