



SAW CUT AS  
REQUIRED TO  
CONSTRUCT  
90 DEGREE  
MITERED  
CORNER



1. ALWAYS START CAPPING WALL FROM THE LOWEST ELEVATION.
2. LAYOUT CAPS PRIOR TO USING ADHESIVE.
3. ALTERNATE SHORT AND LONG CAP FACES EVERY OTHER CAP TO ACHIEVE A STRAIGHT ROW OF CAPS.
4. CUT CAPS TO FIT. VARIOUS COMBINATIONS OF LONG AND SHORT CAP FACES WILL BE NECESSARY FOR RADII GREATER THAN THE MINIMUM.
5. USE EXTERIOR-GRADE CONSTRUCTION ADHESIVE TO SECURE CAPS.
6. SEE DETAIL X ON SHEET WX FOR ADDITIONAL INFORMATION.


**ANCHOR HIGHLAND STONE™  
DESIGN DETAILS - CAP BLOCK**  
 (NOT TO SCALE)


**Anchor**  
 RETAINING WALL SYSTEMS  
*Preferred Worldwide For Selection and Quality*

These graphical representations are intended for preliminary design purposes only, and are not to be used for construction without the signature of a registered professional engineer.

All information herein © 2005 Anchor Wall Systems

Drawn By: AWS  
 Date: 5/22/05  
 Scale: NTS

Drawing Title: ANCHOR HIGHLAND STONE  
 CAP BLOCK DETAILS  
 Project Information: ANCHOR RETAINING WALL SYSTEMS  
 TYPICAL WALL DETAILS