



STEP 1 - PLACE REINFORCEMENT SO LITTLE OR NO OVERLAP OCCURS IN THE RADIUS AREA. IF OVERLAP OCCURS, PLACE 2 TO 3 INCHES OF SAND BETWEEN THE REINFORCEMENT LAYERS.


← PRINCIPLE REINFORCEMENT DIRECTION




STEP 2 - LAY THE NEXT COURSE OF BLOCK. MAKE A MARK ON THE BACK OF THE BLOCKS IN THE AREAS THAT ARE NOT REINFORCED. BACKFILL AND COMPACT THAT COURSE.



STEP 3 - PLACE REINFORCEMENT IN THE AREAS WHERE THE MARKS SHOW GAPS IN THE LOWER REINFORCEMENT PATTERN. CONTINUE NORMAL WALL CONSTRUCTION, REPEATING THESE STEPS AS NEEDED.



MINIMUM RADIUS
4 FT. TO FACE
(TOP COURSE)



X
WX ANCHOR HIGHLAND STONE™
OUTSIDE CURVE W/ GRID
(NOT TO SCALE)

X
WX ANCHOR HIGHLAND STONE™
OUTSIDE CURVES
(NOT TO SCALE)



These graphical representations are intended for preliminary design purposes only, and are not to be used for construction without the signature of a registered professional engineer.

All information herein © 2005 Anchor Wall Systems

Drawn By: AWS
Date: 5/22/05
Scale: NTS

Drawing Title: ANCHOR HIGHLAND STONE
OUTSIDE CURVE DETAILS
Project Information: ANCHOR RETAINING WALL SYSTEMS
TYPICAL WALL DETAILS