




OUTSIDE CURVE




INSIDE CURVE




SAW CUT AS  
REQUIRED TO  
CONSTRUCT  
90 DEGREE  
MITERED  
CORNER



TOP



SPLIT FACE AND END



WALL FACE

1. ALWAYS START CAPPING WALL FROM THE LOWEST ELEVATION.
2. LAYOUT CAPS PRIOR TO USING ADHESIVE.
3. CUT CAPS TO FIT. VARIOUS COMBINATIONS OF LONG AND SHORT CAP FACES WILL BE NECESSARY FOR RADII GREATER THAN THE MINIMUM.
4. ALTERNATE SHORT AND LONG CAP FACES EVERY OTHER CAP TO ACHIEVE A STRAIGHT ROW OF CAPS.
5. USE EXTERIOR-GRADE CONSTRUCTION ADHESIVE TO SECURE CAPS.
6. REFER TO DETAIL X ON SHEET WX FOR ADDITIONAL INFORMATION.



These graphical representations are intended for preliminary design purposes only, and are not to be used for construction without the signature of a registered professional engineer.

All information herein © 2005 Anchor Wall Systems

Drawn By:  
AWS  
Date:  
4/29/2005  
Scale:  
NTS

Drawing Title:  
**ANCHOR LANDMARK SYSTEM  
CAP BLOCK DETAILS**  
Project Information:  
ANCHOR RETAINING WALL SYSTEMS  
TYPICAL WALL DETAILS